



1. Turn back of the fire blanket and find the installation hole on the top.



2. Open the cover on the top of the box



3. Hang the box through the installation hole (Note: the diameter is 9MM in the widest, 5MM in the narrow area)



4. Put the cover back on the top of the box.



5. It is accomplished now.

